


Protection Skid



Available as a user fitted accessory, the protection skid provides unparralled protection of the valves and pipework of Elcometer abrasive blast machines.

Ideal for providing complete protection for your valves and pipework, especially when loading and unloading your machine.

Suitable for use with the Elcometer 1440, 1460 & 20100 abrasive blast machines.

Part Numbers	
Part Number	Description
MT30143-2	Protection Skid for Elcometer 1440
MT30143-3	Protection Skid for Elcometer 1460
MT30143-4	Protection Skid for Elcometer 20100