

Air Supply Ball Valve

Air supply ball valves are fitted between the air hose and the moisture separator to isolate the compressor when undertaking maintenance work. The valves disconnect the compressed air from the blast machine for safe work.



Part Numbers

Part Number	Description
MT30189N	3" (76mm) Male-Female Ball Valve
MT30191N	2" (51mm) Male-Female Ball Valve
MT29177N	1½" (38mm) Male-Female Ball Valve
MT30193N	1¼" (32mm) Male-Female Ball Valve
MT30195N	1" (25mm) Male-Female Ball Valve
MT28610N	¾" (19mm) Male-Female Ball Valve
MT28619N	¼" (6mm) Female-Female Ball Valve
MT30085N	¼" (6mm) Male Adaptor